



BZ33-201NP

Installation Manual

breeze33.com

Table of Contents

Page

Installation Tips	3
Subbase Installation	4
Wiring	5-12
Thermostat Operation	13-14
Thermostat Quick Reference	15-17
Technician Setup Menu	18-23
Terminal Designations	24




Caution

Equipment damage hazard. Do not operate the cooling system if the outdoor temperature is below 50 °F (10 °C) to prevent possible compressor damage.

Installation Tips

Wall locations

The thermostat should be installed approximately 4 to 5 feet above the floor. Select an area with average temperature and good air circulation.



Do not install thermostat in locations:

- Close to hot or cold air ducts
- That are in direct sunlight
- With an outside wall behind the thermostat
- In areas that do not require conditioning
- Where there are dead spots or drafts (in corners or behind doors)
- Where there might be concealed chimneys or pipes

Tip

Pick an installation location that is easy for the user to access. The temperature of the location should be representative of the building.

Subbase Installation



Caution: Electrical Hazard

Failure to disconnect the power before beginning to install this product can cause electrical shock or equipment damage.




Mercury Notice:

All of our products are mercury free. However, if the product you are replacing contains mercury, dispose of it properly. Your local waste management authority can give you instructions on recycling and proper disposal.


For vertical mount put one screw top and one screw bottom.

For horizontal mount put one screw left and one screw right.



Wiring

1 Turn Off Power to Heating/Cooling System



Circuit breaker
box




or
Heating/cooling system
power switch

2 Remove Old Thermostat

Remove old thermostat but leave wallplate with wires attached.

Do not remove wallplate yet




3 Label Wires with Tags

Label the wires using the supplied wire labels as you disconnect them.

Wiring Labels		Étiquettes de fils		Rótulos para los cables					
Apply these wiring labels to each wire with the appropriate terminal designation as you remove it from the existing thermostat.		Lorsque vous retirez les fils des bornes du thermostat existant, collez ces étiquettes sur chaque fil correspondant à la lettre de la borne.		Coloque estos rótulos, con la designación de las terminales, en cada cable al remover los cables del termostato actual.					
B	B	Y2	Y2	C	C	W/E	W/E	F	F
G	G	H	H	L	L	O	O	P	P
R	R	RC	RC	RH	RH	T	T	U	U
VVR	VVR	W	W	W1	W1	W2	W2	W3	W3
X	X	X1	X1	X2	X2	Y	Y	Y1	Y1
AUX	AUX								


Wire Labels



Terminal designation

4 Separate Wallplate from New Thermostat

Remove wallplate from the new thermostat and mount onto wall.




Wallplate

Wiring

5 Separate Wallplate from New Thermostat

Mount the new wallplate using the included screws and anchors.




Drill 3/16-in. holes for drywall
Drill 3/16-in. holes for plaster

6 Connect Wires

Simply match wire labels.


If labels do not match letters on the thermostat, check "Alternate Wiring (Conventional Systems)" on page 9 and connect to terminal as shown (see notes, below).



Wiring

Alternate Wiring (Conventional Systems)

If labels do not match letters on the thermostat, check the chart below and connect to terminal as shown here (See notes, below).



- 1** If there has **C** or **X** wire available then you can connect with **C** terminal, if there is no **C** or **X** wire then no need to connect with C terminal.
- 2** If you have a **heat pump** without auxiliary/backup heat connect **O** or **B**, not both. If you do not have a **heat pump**, do not connect **B**. Wrap bare end of wire with electrical tape.
- 3** Place a jumper (piece of wire) between **Y** and **W** if you are using a heat pump without auxiliary/backup heat



Caution: Electrical Hazard

Failure to disconnect the power before beginning to install this product can cause electrical shock or equipment damage.



Warning:

All components of the control system and the thermostat installation must conform to Class II circuits per the NEC Code.

Wiring

1. If you are replacing a thermostat, make note of the terminal connections on the thermostat that is being replaced. In some cases the wiring connections will not be color coded. For example, the green wire may not be connected to the **G** terminal.
2. Loosen the terminal block screws. Insert wires then retighten terminal block screws.
3. Place nonflammable insulation into wall opening to prevent drafts.

Terminal Designations

	Heat Pump System 1 HEAT 1 COOL / 2 HEAT 1 COOL	Conventional System 1 HEAT 1 COOL / 2 HEAT 1 COOL
R	Transformer Power	Transformer Power
C	Transformer Common	Transformer Common
B	Changeover Valve Energized in HEAT	Energized in HEAT
O	Changeover Valve Energized in COOL	Energized in COOL
G	Fan Relay	Fan Relay
W/E	First Stage of Emergency HEAT	First Stage of HEAT
W2	Second Stage of HEAT/ EMERGENCY HEAT	Second Stage of HEAT
Y	First Stage of HEAT and COOL	First Stage of COOL


Installation Tip:

Do not overtighten terminal block screws, as this can damage the terminal block. A damaged terminal block can keep the thermostat from fitting on the subbase correctly or cause system operation issues. Max Torque = 6in-lbs.


Wiring

- 1** Power supply
- 2** Use either O or B terminals for changeover valve
- 3** Optional 24 VAC common connection when thermostat is used in battery power mode.
- 4** Jumper (not supplied)

2H/1C Heat Pump System




Typical 2H/1C Heat Pump System with separate emergency heat




Conventional System 1H/1C, 2H/1C

(Heat pump set to "OFF" in tech settings)



Note: This thermostat is only compatible with ONE transformer systems.

Thermostat Operation



1 LCD Display

4 Temperature Setpoint Buttons

2 Fan Switch

5 User Buttons

3 System Switch

- 1 LCD Display**
See page 15 for details about this display read out.
- 2 Fan Switch**
Select **ON** or **AUTO**. **ON** will run the fan continuously. **AUTO** will cycle the fan on only when the heating or cooling system is on.
- 3 System Switch**
Selects the operation mode on your HVAC system. Selecting **HEAT** turns on the heat mode. Selecting **COOL** turns on the cool mode. Selecting **OFF** turns both heating and cooling off.
- 4 Temperature Setpoint Buttons**
Press the + or - buttons to select the desired room temperature.
- 5 User Buttons**
Use these buttons to set up your options. Refer to the next page for detail.




Caution:

When the battery icon  appears replace your AAA batteries immediately. Failure to do so may result in your heating & cooling system becoming inoperable. Freezing or over heating can occur.




Thermostat Quick Reference

Days of the week and time.

Displays the user selected setpoint temperature.



Low Battery Indicator:
Replace batteries when indicator is shown.

System Operation Indicators:
The , , or  icon will display when the COOL, HEAT, or (fan) is on.

Buttons Options

Indicates the current room temperature.


NOTE: The compressor delay feature is active if these icons are flashing. The compressor will not turn on until the 5 minute delay has elapsed.



Important:


The low battery indicator is displayed when the 2x AAA battery power is low.

Battery Door Information



Use the finger bevel on the lower portion of the thermostat to open the easy access battery door.

Replace with 2x AAA Alkaline Batteries. High quality Alkaline batteries are recommended.




Thermostat Quick Reference

Filter Change Reminder







If your HVAC contractor has configured the thermostat to remind you when the air filter needs to be changed, you will see **FILTER** in the display when your air filter needs to be changed.

Resetting the filter change reminder: When **FILTER** reminder is displayed, you should change your air filter and reset the reminder by holding down the second button from the top left side of the thermostat for 3 seconds.

Hold down 3 seconds,
to reset filter reminder.



Set Time

1. Press the **MENU** button
2. Press **SET TIME**
3. Day of the week will be flashing. Use the  or  key to select the current day of the week.
4. Press **NEXT STEP**
5. The current hour is flashing. Use the  or  key to select the current hour. When using 12-hour time, make sure the correct a.m. or p.m. choice is selected.
6. Press **NEXT STEP**
7. Minutes are now flashing. Use the  or  key to select current minutes.
8. Press **DONE** when completed.

Technician Setup Menu

- 1.Press MENU button.
 - 2.Press and hold TECH SET button for 3 seconds.
 - 3.Configure the installer options as desired using the table below.
Use the + OR - keys to change settings and the NEXT STEP or PREV STEP key to move from one option to another.
- Note: Only press DONE key when you want to exit the Technician Setup Options.

Technician Setup Menu

Tech Settings	LCD Will Show	Adjustment Options	Default
Filter Change Reminder	<p>Next Step OFF</p> <p>FL SE</p> <p>Prev Step</p>	You can adjust the filter change reminder from OFF to 2000 hours of runtime in 50 hour increments. Tap the second button from the top left side of the thermostat to display the current filter elapsed runtime.	OFF
Room Temperature Calibration	<p>Next Step [AL</p> <p>0°F</p> <p>Prev Step</p>	You can adjust the room temperature display to read 3° above or below the factory calibrated reading.	0
Minimum Compressor On Time	<p>Next Step OFF</p> <p>AN ON</p> <p>Prev Step</p>	You can select the minimum compressor run time from "off", "3", "4", or "5" minutes. If 3,4, or 5 is selected, the compressor will run for at least the selected time before turning off.	OFF

Technician Setup Menu

Tech Settings	LCD Will Show	Adjustment Options	Default
Compressor Short Cycle Delay	<p>The compressor short cycle delay protects the compressor from short cycling. This feature will not allow the compressor to be turned on for 5 minutes after it was last turned off.</p>	<p>Next Step ON</p> <p>CO OF</p> <p>Prev Step</p> <p>Selecting "ON" will not allow the compressor to be turned on for 5 minutes after the last time the compressor was switched off. Select "OFF" to remove this delay.</p>	ON
Cooling Swing	<p>The swing setting often called "cycle rate," "differential" or "anticipation" is adjustable. A smaller swing setting will cause more frequent cycles and a larger swing setting will cause fewer cycles.</p>	<p>Next Step dF CO</p> <p>0.5 °F</p> <p>Prev Step</p> <p>The cooling swing setting is adjustable from 0.2° to 2°. For example: A swing setting of 0.5° will turn the cooling on at approximately 0.5° above the setpoint and turn the cooling off at approximately 0.5° below the setpoint.</p>	0.5
Heating Swing	<p>The swing setting often called "cycle rate," "differential" or "anticipation" is adjustable. A smaller swing setting will cause more frequent cycles and a larger swing setting will cause fewer cycles.</p>	<p>Next Step dF HE</p> <p>0.4 °F</p> <p>Prev Step</p> <p>The heating swing setting is adjustable from 0.2° to 2°. For example: A swing setting of 0.5° will turn the heating on at approximately 0.5° below the setpoint and turn the heating off at approximately 0.5° above the setpoint.</p>	0.4

Technician Setup Menu

Tech Settings	LCD Will Show	Adjustment Options	Default
<p>F or C</p>	<p>Select F for Fahrenheit temperature read out or select C for Celsius read out.</p>	<p>Next Step</p> <p style="text-align: center;">OF 82 °F</p> <p>Prev Step</p> <p>F for Fahrenheit C for Celsius</p>	<p>F</p>
<p>12 or 24 Hour Clock</p>	<p>You can select either a 12 or 24 hour clock setting.</p>	<p>Next Step</p> <p style="text-align: center;">24H</p> <p>Prev Step</p> <p>Use the <input type="checkbox"/>+ and <input type="checkbox"/>- to select 12 or 24 hour clock.</p>	<p>24H</p>
<p>Fan Operation</p>	<p>Select GAS for systems that control the fan during a call for heat. Select ELEC to have the thermostat control the fan during a call for heat.</p>	<p>Next Step</p> <p style="text-align: center;">GAS</p> <p>Prev Step</p> <p>GAS - GS or ELEC - EL</p>	<p>GAS</p>

Technician Setup Menu

Tech Settings	LCD Will Show	Adjustment Options	Default
Heat Pump	HEAT PUMP 00	OFF configures the thermostat for conventional systems. ON configures the thermostat for heat pump systems.	ON
GAS AUX	AG ON	Use the + and - to select on or off.	ON

W2	-----	Auxiliary heat relay
Y	-----	Compressor relay
G	-----	Fan relay
O	-----	Heat pump changeover valve energized in cooling
R	-----	Transformer power
C	-----	Common wire from system transformer
B	-----	Heat pump changeover valve energized in heating
W/E	-----	Emergency heat relay

Note:

In many systems with no emergency heat relay a jumper can be installed between E and W2.

Warranty

WARRANTY

Breeze33 Products LLC (Breeze33) warrants to the ORIGINAL PURCHASER that its thermostats shall be free from defects in material and workmanship under normal use and service for a five (5) years. This warranty cannot be transferred - it is extended only to the original Purchaser or First User of the Product. By accepting and keeping this Product you agree to all of the warranty terms and limitations of liability described below.

Breeze33's obligations under the warranty set forth above shall be to replace any Breeze33 Thermostat which is defective.

WHAT IS NOT COVERED?

The warranty above does not cover and Breeze33 is not liable for, (i) installation, (ii) any labor charges or (iii) products which have been damaged as a result of any accident, misuse, abuse, neglect, improper installation or maintenance, the use of abrasive or organic solvent cleaners, modification, failure to use the register, grille, or diffuser in accordance with instructions provided by Breeze33.

HOW TO OBTAIN WARRANTY SERVICE

Contact our warranty department at 740-314-4404 to report the defect. Return failed product with proof of purchase, your name, and address within 30 days of failure to:

Breeze33 Products LLC
350 Courtney Road Sebring,
Ohio 44672 USA

LIMITATION OF LIABILITY

Breeze33's liability on any claim of any kind, including, without limitation, warranty, negligence and/or breach of contract, shall in no case exceed the purchase price paid by the Customer. IN NO EVENT SHALL BREEZE33 BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING, WITHOUT LIMITATION, DAMAGE TO PROPERTY) OR PUNITIVE DAMAGES, DAMAGES IN THE NATURE OF PENALTIES OR SIMILAR OR RELATED DAMAGES OF ANY KIND.

DISCLAIMER OF WARRANTIES

BREEZE33 EXPRESSLY DISCLAIMS ALL WARRANTIES, EXCEPT AS EXPLICITLY STATED HEREIN, TO THE FULLEST EXTENT PERMITTED BY LAW, WHETHER WRITTEN, ORAL, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NONINFRINGEMENT. THIS DISCLAIMER INCLUDES ANY ORAL WARRANTIES OR REPRESENTATIONS MADE OR IMPLIED BY ANY AGENT, EMPLOYEE, SUBCONTRACTOR, MANAGER, DIRECTOR AND/OR REPRESENTATIVE OF BREEZE33.

Installation Manual